


DIY2419 Dorota square shopper

dorotasquashopper

36 × 42 × 15 cm

Seam allowance is included on all patterns:
All over 0,7 cm




You need to cut the following parts

Part 1	Front	x 1
Part 2	Side	x 2

You need the following fabric and accessories


Fabric: w/135 cm 55 cm



Accessories:

- 120 cm webbing ribbon 38 mm
- 320 cm bias tape 18 mm


Symbols you may find on your patterns



Grain line



Fold line



Notch




Gathering



Interlining



Cut line



Placement of button and buttonhole

10 CM

Self
made®

All rights
reserved
Selfmade®


CONTROL SQUARE:
Print this page, to check the
square measurements:
If the measurements do not match,
please adjust your printer settings.

CONTROL PAGE FIT:
In print preview check page margin.
Margin have to be equal on
all 4 sides of each page.

X


10 CM

Glue or tape your patterns together as shown in the diagram



2


3



4

**Self
made[®]**

DIY2419
PART 1



5



+

6S

+



DIY2419
PART 2

SIDE
✂ x 2

INCL. SEAM ALLOWANCE

Free download from

8

+

FRONT

✂ x1

INCL. SEAM ALLOWANCE

n Selfmade.com

ad 9

FOLDLINE

e¹⁰

+